

20/10/2021

## EXP 4 : THERMAL CONDUCTIVITY OF A CONDUCTOR

AIM:

To determine the thermal conductivity of a good conductor

APPARATUS:

Steam chamber, Long metal rod, thermometers, heater.

FORMULA:

Let B and C be reference points on the rod.

- Heat flowing per second across B = Heat lost per second from B to C.


$$KA \left( \frac{d\theta}{dx} \right)_B = \int_B^C A dx \rho s \left( \frac{d\theta}{dt} \right)$$

$$K = \frac{\rho s \int_B^C \left( \frac{d\theta}{dt} \right) dx}{\left( \frac{d\theta}{dx} \right)} \quad \text{Wm}^{-1}\text{K}^{-1}$$


K  $\rightarrow$  Thermal conductivity $\rho \rightarrow$  Density $s \rightarrow$  Specific Heat Capacity.

DIAGRAM:


a) Basic setup



b) Dynamic Setup



c) Static setup:



### PROCEDURE :

- i) Firstly, start with the static experiment, to find  $\left(\frac{d\theta}{dx}\right)_B$ . Take 4 thermometers and place them aside. Now heat the given conductor to the required temperature.
  - Place the thermometers side by side from the given reference points B to C.
  - Now wait for half an hour till the steady state is reached.
  - Record the temperature of the rod at different points b/w the points B & C.
  - Mark temperature of first thermometer with the highest temperature which will be used as reference in the second part of the experiment. ( $T_1$ ).
- ii) Dynamic experiment to find :-  $\left(\frac{d\theta}{dt}\right)_{dx}$ .
  - First take a small piece of the sample and heat it till it reaches  $T_1 + 10^\circ\text{C}$  ( $T_1$  - Reference temperature).
  - Now wait till it reaches steady state.
  - Now attach a thermometer to the small sample and let it cool down.
  - While sample is cooling down note temp vs time for every 5 minutes.
  - After noting down the values make a graph to find  $\int_B^C \left(\frac{d\theta}{dt}\right) dx$  taking B as reference on graph.
  - After finding all required information, substitute them in the formula for 'k'.

# TABULATION:

## i) Static Experiment:

Reference  
points

$b = 15\text{cm}$   
&

$c = 55\text{cm}$

Distance (cm)	Temperature ( $^{\circ}\text{C}$ )
16.10	110
21.0	90
26.5	64
31.8	52
36.8	41
41.9	36
51.6	31

## ii) Dynamic Experiment:

Time (min)	Temperature ( $^{\circ}\text{C}$ )
0	120
5	113
10	89
15	78
20	70
25	62
30	57
35	51
40	47
45	44
50	41
55	39
60	37
65	36




①

Scale :  
 on x axis, 1 unit = 5 cm  
 on y axis, 1 unit = 6 cm

$$\tan \alpha = \frac{dy}{dx} = \frac{60}{25} = 2.4$$

$$\frac{dy}{dx} = 2.4$$






②


Scale -

On X-axis / unit = 5 min

On Y-axis / unit = 5°C







### CALCULATIONS:

i) From static experiment & graph 1 :

$$\left(\frac{d\theta}{dx}\right)_B = \tan \alpha = \frac{DB}{DE} = \frac{110^\circ\text{C}}{2.15}$$

$$\Rightarrow \frac{383.15}{0.25} = 1532.6$$

ii) From dynamic experiment of graph 2 and 3.

$$\text{Area under graph 3} = \int_B^C \left(\frac{d\theta}{dt}\right) dx$$

$$\Rightarrow \int_B^C \left(\frac{d\theta}{dt}\right) dx = 65 \text{ sq. units (approx)}$$

$$\therefore K = \frac{es \int_B^C \left(\frac{d\theta}{dt}\right) dx}{\left(\frac{d\theta}{dx}\right)_B} = \frac{es \times \text{Area shaded}}{DB/BE} \text{ Wm}^{-1}\text{K}^{-1}$$

$$K = \frac{6900 \times 460 \times 65}{1532.6} = 134614.3807 \text{ Wm}^{-1}\text{K}^{-1}$$

### RESULT:

Thermal conductivity of conductor is  $134614.38 \text{ Wm}^{-1}\text{K}^{-1}$